

## Pit Bull Spools Fitting Chart Revised 12/26/18

<b>APRILIA</b>	<a href="#"><u>Page 1</u></a>	<b>BMW</b>	<a href="#"><u>Page 1</u></a>
<b>BUELL</b>	<a href="#"><u>Page 2</u></a>	<b>DUCATI</b>	<a href="#"><u>Page 2</u></a>
<b>HONDA</b>	<a href="#"><u>Page 3</u></a>	<b>KAWASAKI</b>	<a href="#"><u>Page 3</u></a>
<b>KTM</b>	<a href="#"><u>Page 4</u></a>	<b>SUZUKI</b>	<a href="#"><u>Page 4</u></a>
<b>TRIUMPH</b>	<a href="#"><u>Page 5</u></a>	<b>YAMAHA</b>	<a href="#"><u>Page 6</u></a>

### APRILIA

<b>RS 250</b>	F0013-000	6mm
<b>RSV MILLE</b>	F0013-000	6mm
<b>TUONO</b>	F0013-000	6mm
<b>FALCO</b>	F0013-000 w/ Falco spacers	6mm w/ custom spacers
<b>RSV4</b>	F0013-000	6mm

**ANY SPOOLED MODELS NOT LISTED WILL USE 6MM SPOOLS**

### BMW

<b>R1100S</b>	F0041-000	Bike Specific Spool Kit
<b>S1000RR</b>	F0009D-000	8mm w/ 0.135" spacer
<b>S1000R</b>	F0009D-000	8mm w/ 0.135" spacer
<b>HP4</b>	F0009D-000	8mm w/ 0.135" spacer
<b>S1000SX</b>	F0009D-000	8mm w/ 0.135" spacer

**ANY MODELS NOT LISTED WILL NOT USE SPOOLS OR HAVE NOT BEEN CHECKED YET**

## BUELL/EBR

<b>1125R ('09 &amp; up)</b>	F0013-000 – 6mm	6mm
<b>1190 models</b>	F0013-000 – 6mm	6mm
We strongly recommend our Delrin/Plastic spools on all Buell/EBR bikes. Use of a stand using factory spools can damage your swingarms.		
<b>ANY SPOOLED MODELS NOT LISTED WILL USE 6MM SPOOLS</b>		

## DUCATI

<b>749 ('05 &amp; up)</b>	F0009-000	8mm
<b>851, 888</b>	Factory, welded on	
<b>821 Monster</b>	F0013A-000	6mm w/ 0.12" spacer
<b>899/959 Panigale</b>	F0013A-000	6mm w/ 0.12" spacer
<b>900 Monster (thru mid '01)</b>	Factory, welded on	
<b>999 ('05 &amp; up)</b>	F0009-000	8mm
<b>999R</b>	F0009-000	8mm
<b>Multistrada Enduro 1200</b>	F0009C-000	8mm w/ 0.6" spacer
<b>ANY MODELS NOT LISTED WILL NOT USE SPOOLS</b>		



# KAWASAKI

<b>EX250 (up to '07)</b>	No spools	
<b>Ninja 250/300 ('08 &amp; up)</b>	F0023-000	10mm
<b>Ninja 400</b>	F0009D-000	8mm w/ 0.135" spacer
<b>ZX6R ('95 - '97)</b>	F0011-000	12mm w/ two short adapters
<b>ZX6R/ZX6RR('98 - '12)</b>	F0023-000	10mm
<b>ZX6R ('13 - '17)</b>	F0009-000	8mm
<b>ZZR600</b>	F0023-000	10mm
<b>Ninja 650R (up to '16)</b>	F0023-000	10mm
<b>Ninja 650R / Z650 ('17)</b>	F0009-000	8mm
<b>Versys 650(up to '12)</b>	F0023-000	10mm
<b>Versys 650('13 and up)</b>	F0009-000	8mm
<b>Vulcan 650</b>	F0023-000	10mm
<b>ZX7R (All)</b>	F0010-000	12mm w/ short/long adapters
<b>ZX9R (up to '97)</b>	F0010-000	12mm w/ short/long adapters
<b>ZX9R('98 &amp; on)</b>	F0023-000	10mm
<b>Z800</b>	F0009D-000**	8mm w/ 0.135" spacer **Remove before riding
<b>Z900</b>	F0009D-000	8mm w/ 0.135" spacer
<b>Z900RS</b>	F0009C-000**	8mm w/ 0.6" spacer **Remove before riding
<b>ZX10R (up to '10)</b>	F0023-000	10mm
<b>ZX10R ('11-'17)</b>	F0009-000	8mm
<b>ZRX1100/ZRX1200</b>	F0023-000	10mm
<b>ZX12/ZX14</b>	F0023-000	10mm
<b>Ninja 1000/Z1000 (up to '13)</b>	F0023-000*	10mm *do not use delrin
<b>Ninja 1000/Z1000 ('14 &amp; up)</b>	F0009-000*	8mm *do not use delrin

## KTM

<b>RC390 / Duke 390</b>	F0023-000	10mm
<b>690 Superduke</b>	F0023A-000	10mm w/ 1.5 thread pitch
<b>990 Superduke</b>	F0023A-000	10mm w/ 1.5 thread pitch
<b>RC8R</b>	F0023A-000	10mm w/ 1.5 thread pitch
		All KTM's using the F0023A-000 require special bolts and are only available with Delrin spool kits

## SUZUKI

**Any and all Suzuki bikes that have spooled swingarms, use 8mm (F0009-000) spools. There are no exceptions as of the date of this update. We will update the fitting chart if this changes in the future.**

<b>GSX250R</b>	F0009-000	8mm
<b>500 Gamma</b>	F0009-000	8mm
<b>RF600R/RF900R</b>	F0009-000	8mm
<b>GSXR600</b>	F0009-000	8mm
<b>SV650</b>	F0009-000	8mm
<b>GSXR750</b>	F0009-000	8mm
<b>GSXR1000 ('01 &amp; on)</b>	F0009-000	8mm
<b>SV1000</b>	F0009-000	8mm
<b>TL1000S/TL1000R</b>	F0009-000	8mm
<b>GSXR1100</b>	F0009-000	8mm
<b>GSXR1300 Hayabusa</b>	F0009-000	8mm
<b>B King</b>	F0009-000	8mm

## TRIUMPH

<b>Daytona 675 (up to '10)</b>	F0013-000	6mm
<b>Daytona 675 ('11-'12)</b>	F0009-000 ***	8mm
<b>Daytona 675 ('13 &amp; up)</b>	F0009C-000 ***	8mm w/ 0.6" spacer
<b>Street Triple 675 (up to '10)</b>	F0013-000	6mm
<b>Street Triple 675 ('11-'12)</b>	F0009-000	8mm
<b>Street Triple 675 ('13 &amp; up)</b>	F0009C-000	8mm w/ 0.6" spacer
<b>Street Triple 765</b>	F0009C-000	8mm w/ 0.6" spacer
<b>Tiger 800/800XC</b>	F0009C-000	8mm w/ 0.6" spacer
<b>Thruxton 900</b>	No spools	
<b>Thruxton 1200 ('16+)</b>	F0009-000	8mm
<b>Bobber ('17+)</b>	F0009C-000	8mm w/ 0.6" spacer

\*\*\* On '12-'13 model Triumph 675, verify your spool size as it may be 6mm or 8mm. There were some inconsistencies based on VIN

**ANY MODELS NOT LISTED WILL NOT USE SPOOLS OR HAVE NOT BEEN CHECKED**

# YAMAHA

<b>TZ250</b>	F0023-000	
<b>TZR250</b>	F0023-000	
<b>R3</b>	F0013-000	
<b>FZR400 ('90 Only)</b>	F0023-000	
<b>FZR400/600/1000 (exc. '90 FZR400)</b>	No spools	
<b>YZF600(all)/SECA II</b>	No spools	
<b>R6 ('99 &amp; up)</b>	F0013-000	
<b>R6S ('06 -'09)</b>	F0013-000	
<b>YZF750/YZF1000 (ex R1)</b>	F0023-000	
<b>FZ-07</b>	No spools	
<b>FZ8</b>	F0013-000	
<b>FZ-09</b>	F0013-000	
<b>FZ1('01 &amp; up)</b>	No spools	
<b>R1 ('98 &amp; up)</b>	F0013-000	
<b>FZ10 ('16 &amp; up)</b>	F0013-000	
<b>V-MAX ('09 &amp; up)</b>	F0013-000	
<b>ANY MODELS NOT LISTED WILL NOT USE SPOOLS OR HAVE NOT BEEN CHECKED</b>		