

Pit Bull Spools Fitting Chart Revised 4/13/22

APRILIA	<u>Page 1</u>	BMW	<u>Page 1</u>
BUELL	<u>Page 2</u>	DUCATI	<u>Page 2</u>
HONDA	<u>Page 3</u>	KAWASAKI	<u>Page 3</u>
KTM	<u>Page 4</u>	SUZUKI	<u>Page 4</u>
TRIUMPH	<u>Page 5</u>	YAMAHA	<u>Page 6</u>

APRILIA

RS 250	F0013-000	6mm
RSV MILLE	F0013-000	6mm
TUONO	F0013-000	6mm
FALCO	F0013-000 w/ Falco spacers	6mm w/ custom spacers
RSV4	F0013-000	6mm

ANY SPOOLED MODELS NOT LISTED WILL USE 6MM SPOOLS

BMW

R1100S	F0041-000	Bike Specific Spool Kit
S1000RR	F0009E-000	8mm w/ 0.18" spacer
S1000R	F0009E-000	8mm w/ 0.18" spacer
HP4	F0009E-000	8mm w/ 0.18" spacer
S1000SX	F0009E-000	8mm w/ 0.18" spacer

ANY MODELS NOT LISTED WILL NOT USE SPOOLS OR HAVE NOT BEEN CHECKED YET

BUELL/EBR

1125R ('09 & up)	F0013-000	6mm
1190 models	F0013-000	6mm
We strongly recommend our Delrin/Plastic spools on all Buell/EBR bikes. Use of a stand using factory spools can damage your swingarms.		
ANY SPOOLED MODELS NOT LISTED WILL USE 6MM SPOOLS		

DUCATI

749 ('05 & up)	F0009-000	8mm
851, 888	Factory, welded on	
821 Monster	F0013A-000	6mm w/ 0.12" spacer
899/959 Panigale	F0013A-000	6mm w/ 0.12" spacer
Monster Plus	F0013A-000	6mm w/ 0.12" spacer
900 Monster (thru mid '01)	Factory, welded on	
999 ('05 & up)	F0009-000	8mm
999R	F0009-000	8mm
Multistrada 950S	F0009C-000	8mm w/ 0.6" spacer
Multistrada Enduro 1200	F0009C-000	8mm w/ 0.6" spacer
ANY MODELS NOT LISTED WILL NOT USE SPOOLS		

HONDA

RS125 '95 & on	F0009-000	8mm
RC51 '00,'02 & on	F0009-000	8mm
RC51 '01	No spools	
CBR600RR	F0009-000	8mm
CBR954RR	F0009-000	8mm
CBR1000RR	F0009-000	8mm

INDIAN

FTR 1200	F0009-000	

ANY MODELS NOT LISTED WILL NOT USE SPOOLS

KAWASAKI

EX250 (up to '07)	No spools	
Ninja 250/300 ('08+)	F0023-000	10mm
Ninja 400	F0009E-000	8mm w/ 0.18" spacer
ZX6R ('95 - '97)	F0011-000	12mm w/ two short adapters
ZX6R/ZX6RR('98 - '12)	F0023-000	10mm
ZX6R ('13 - '20)	F0009-000	8mm
ZZR600	F0023-000	10mm
Ninja 650R (up to '16)	F0023-000	10mm
Ninja 650R / Z650 ('17+)	F0009-000	8mm
Versys 650(up to '12)	F0023-000	10mm
Versys 650('13+)	F0009-000	8mm
Vulcan S 650	F0023-000	10mm
ZX7R (All)	F0010-000	12mm w/ short/long adapters
ZX9R (up to '97)	F0010-000	12mm w/ short/long adapters
ZX9R('98+)	F0023-000	10mm
Z800	F0009E-000**	8mm w/ 0.18" spacer **Remove before riding
Z900	F0009E-000	8mm w/ 0.18" spacer
Z900RS	F0009C-000**	8mm w/ 0.6" spacer **Remove before riding
ZX10R (up to '10)	F0023-000	10mm
ZX10R ('11-'20)	F0009-000	8mm
ZRX1100/ZRX1200	F0023-000	10mm
ZX12/ZX14	F0023-000	10mm
Ninja 1000/Z1000 (up to '13)	F0023-000*	10mm *do not use delrin
Ninja 1000/Z1000 ('14+)	F0009-000*	8mm *do not use delrin

KTM

RC390/Duke390 (early models)	F0023-000	10mm
RC 390/Duke 390 (? - '20)	F0023A-000	10mm w/ 1.5 thread pitch
690 Superduke	F0023A-000	10mm w/ 1.5 thread pitch
790 Duke	F0023A-000	10mm w/ 1.5 thread pitch
890 Duke	F0023A-000	10mm w/ 1.5 thread pitch
990 Superduke	F0023A-000	10mm w/ 1.5 thread pitch
RC8R	F0009-000	8mm
On 390 models, verify your thread pitch as we are not sure when the change occurred.		All KTM's using the F0023A-000 require special bolts and are only available with Delrin spool kits

SUZUKI

Any and all Suzuki bikes that have spooled swingarms, use 8mm (F0009-000) spools. There are no exceptions as of the date of this update. We will update the fitting chart if this changes in the future.

GSX250R	F0009-000	8mm
500 Gamma	F0009-000	8mm
RF600R/RF900R	F0009-000	8mm
GSXR600	F0009-000	8mm
SV650	F0009-000	8mm
GSXR750	F0009-000	8mm
GSXR1000 ('01+)	F0009-000	8mm
SV1000	F0009-000	8mm
TL1000S/TL1000R	F0009-000	8mm
GSXR1100	F0009-000	8mm
GSXR1300 Hayabusa	F0009-000	8mm
B King	F0009-000	8mm

TRIUMPH

Daytona 675 (up to '10)	F0013-000	6mm
Daytona 675 ('11-'12)	F0009-000 ***	8mm
Daytona 675 ('13 & up)	F0009C-000 ***	8mm w/ 0.6" spacer
Street Triple 675 (up to '10)	F0013-000	6mm
Street Triple 675 ('11-'12)	F0009-000	8mm
Street Triple 675 ('13 & up)	F0009C-000	8mm w/ 0.6" spacer
Street Triple 765	F0009C-000	8mm w/ 0.6" spacer
Tiger 800/800XC	F0009C-000	8mm w/ 0.6" spacer
Thruxton 900	No spools	
Thruxton 1200 ('16+)	F0009-000	8mm
Bobber ('17+)	F0009C-000	8mm w/ 0.6" spacer

*** On '12-'13 model Triumph 675, verify your spool size as it may be 6mm or 8mm. There were some inconsistencies based on VIN

ANY MODELS NOT LISTED WILL NOT USE SPOOLS OR HAVE NOT BEEN CHECKED

YAMAHA

TZ250	F0023-000	10mm
TZR250	F0023-000	10mm
R3	F0013-000	6mm
FZR400 ('90 Only)	F0023-000	10mm
FZR400/600/1000 (exc. '90 FZR400)	No spools	
YZF600(all)/SECA II	No spools	
R6 ('99 & up)	F0013-000	6mm
R6S ('06 -'09)	F0013-000	6mm
YZF750/YZF1000 (ex R1)	F0023-000	10mm
FZ or MT-07	No spools	
FZ8	F0013-000	6mm
FZ or MT-09	F0013-000	6mm
FZ1('01 & up)	No spools	
R1 ('98 & up)	F0013-000	6mm
FZ or MT-10 ('16 & up)	F0013-000	6mm
V-MAX ('09 & up)	F0013-000	6mm
ANY MODELS NOT LISTED WILL NOT USE SPOOLS OR HAVE NOT BEEN CHECKED		