

Using the **pit bull** Norton Rear Stand:

The Pit Bull Rear Stand for the Norton Commando addresses the specific needs of this motorcycle:

- Our stand is designed to work with our specially designed Pit Bull Norton Spool Kit(sold separately). Our spool kit includes replacement lower rear shock bolts(and nuts).
- The stand is height and width adjustable so be sure to set your width and height as needed for your motorcycle before attempting to use the stand.



To Use:

First set the width of the spooled or standard style top supports using a 19mm wrench. Start on a smooth, level surface.

Tilt bike to vertical and balance in position using your left hand on the rear seat of the bike. Using your right hand, bring stand into position behind the bike.

Hook the spools mounted to the rear shock bolts with “V” shaped top supports.

To lower bike: Hold the rear seat with your left hand and prepare to balance bike, then lift the handle of the stand.



Use the 3/8 - 24 x 2-3/4 bolt and the Nylock nut on the right side.

In the pictures on either side of this text you can see the spooled supports as they look while in use.



Use the 3/8 - 24 x 2-3/4” bolt and the thin hex nut on the left side.

Please call us if you have any questions regarding installation of the spool kit and/or using your Pit Bull Norton Rear Stand

Pit Bull Products, Inc.
614 Pearl Avenue
Huntsville, AL 35801



Toll Free: (877) 533-1977
Fax: (256) 533-3395
Website: www.pit-bull.com
E-mail: info@pit-bull.com