

Using the **pit bull** Trailer Restraint on a solid rear axle:

Pit Bull's Trailer Restraint System works on a variety of motorcycles, and one method of securing solid rear axles involves using two pins that cover the head of the axle bolt and the axle nut. These pins often look like sockets and may or may have a hex shaped or round inner hole.

Step 1: Secure the motorcycle with side stand, rear stand, or have someone hold the bike for you. Ensure that there are no cotter pins, axle sliders, aftermarket axle blocks, or safety wire that will prevent proper engagement of our pins.

Step 2: Install one hex pin using provided retaining/safety pin(s) into TRS pin housing. Check to ensure the hex pin goes all the way over the axle bolt(or nut) and does not catch on any burrs that might be present on the edges of the nut.

Step 3: Now push the other pin through the housing and over the axle nut(or bolt head) on the opposite side of the motorcycle. The pin should fit snug and there should be no side to side play. Ensure that all safety pins and/or retaining pins are in place and secure before attempting to transport the motorcycle.

Pit Bull Products, Inc.
614 Pearl Avenue
Huntsville, AL 35801



Phone: (256) 533-1977
Fax: (256) 533-3395
Website: www.pit-bull.com
E-mail: info@pit-bull.com



Using the **pit bull** Trailer Restraint on a solid rear axle:

Pit Bull's Trailer Restraint System works on a variety of motorcycles, and one method of securing solid rear axles involves using two pins that cover the head of the axle bolt and the axle nut. These pins often look like sockets and may or may have a hex shaped or round inner hole.

Step 1: Secure the motorcycle with side stand, rear stand, or have someone hold the bike for you. Ensure that there are no cotter pins, axle sliders, aftermarket axle blocks, or safety wire that will prevent proper engagement of our pins.

Step 2: Install one hex pin using provided retaining/safety pin(s) into TRS pin housing. Check to ensure the hex pin goes all the way over the axle bolt(or nut) and does not catch on any burrs that might be present on the edges of the nut.

Step 3: Now push the other pin through the housing and over the axle nut(or bolt head) on the opposite side of the motorcycle. The pin should fit snug and there should be no side to side play. Ensure that all safety pins and/or retaining pins are in place and secure before attempting to transport the motorcycle.

Pit Bull Products, Inc.
614 Pearl Avenue
Huntsville, AL 35801



Phone: (256) 533-1977
Fax: (256) 533-3395
Website: www.pit-bull.com
E-mail: info@pit-bull.com

