

# Using a Pit Bull Standard Rear Stand:



- 1) Top Supports are separate or installed upside down for shipping - orient as shown before use.
- 2) Set width of each tab close to outside of swingarm and tighten bolts.
- 3) While standing on left side of bike, hold bike upright (vertical) by seat or tail section with left hand. Then bring stand into place with right hand.
- 4) Place rubber pads (heater hose) under swingarm and start to press down (you will feel the bike get stable). Then follow through to lift the bike.

## Notes:

- Always ensure bottom of swingarm and rubber pads of stand are clean and free of oils (even new bikes often have an oily film on swingarm).
- For bikes (like Honda) with alum. swingarms, lift from behind weld seam (as shown in photo) to prevent sliding.
- For Honda CBR929RR use shim (p/n F0002-002) on right side to level bike.

Pit Bull Products, Inc.  
614 Pearl Avenue  
Huntsville, AL 35801



Phone: (256) 533-1977  
Fax: (256) 533-3395  
Website: [www.pit-bull.com](http://www.pit-bull.com)  
E-mail: [info@pit-bull.com](mailto:info@pit-bull.com)